



55" FullHD DIGITAL SIGNAGE

ASF5515A-TA









QUICK REFERENCE GUIDE


Thank you for purchasing the unit.

Safety Instruction



1. **Read Instructions** - All the safety and operating instructions should be read before the appliance is operated.
2. **Retain Instructions** - The safety and operating instructions should be retained for future reference.
3. **Heed Warnings** - All warnings on the appliance and in the operating instructions should be adhered to.
4. **Follow Instructions** - All operating instructions should be followed.
5. **Battery** - Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
6. **Earthing Connection** - The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.
7. **Water and Moisture** - The appliance should not be used near water.
8. **Ventilation** - The appliance should be well situated so that its location or position does not interfere with its proper ventilation.
9. **Heat** - This appliance should be placed away from heat sources such as radiators, heat registers and stoves.
10. **Power Sources** - The appliance should only be connected to a power supply as described in the operating instructions or as marked on the appliance.
11. **Grounding or Polarization** - Precautions should be taken.
12. **Power Cord Protection** - Power supply cord should be located so that it is not likely to be walked on, or pinched by items placed upon it.
13. **Cleaning** - The appliance should be cleaned only as recommended by the manufacturer.
14. **Non-use Periods** - The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
15. **Objects and Liquids** - Care should be taken so that objects do not fall, and liquids are not spilled into the enclosure through openings.
16. **Conditions Requiring Service** - The appliance should be serviced by qualified service personnel when:
 - The power-supply cord or the plug has been damaged.
 - Objects have fallen on or liquid has been spilled into the appliance.
 - The appliance has been exposed to rain.
 - The appliance does not appear to operate normally or exhibits a marked change in performance.
17. This appliance should not be exposed to water and no objects filled with liquids such as a vase should be placed on the unit. Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
18. Only for indoor used. (🏠).
19. **Caution** - There is a button cell inside. Place away from the old and kids, avoiding to be eaten by mistake. Once happened, please go to hospital for treating immediately.
20. Keep the key properly. There are high voltage and dangerous live parts inside. It's better to maintain and repair with a professional.

 <p>Warning</p> <p>High voltages are used in the operation of this product. Do not remove the back cover of the cabinet. Refer servicing to qualified service personnel.</p>	 <p>Warning</p> <p>To prevent fire or electrical shock hazard, do not expose the main unit to rain or moisture.</p>	 <p>Warning</p> <p>Do not insert foreign objects into the appliance slots or openings. Never spill any kind of liquid on the appliance receiver.</p>
 <p>Caution</p> <p>If the appliance is placed into a confined space, ensure that the minimum distances are observed as shown. Heat build up can reduce the service life of your appliance, and can also be dangerous.</p>	 <p>Caution</p> <p>Never stand on, lean on, push or apply force to the product or its stand. You should pay special attention to children.</p>	 <p>Caution</p> <p>Do not place the main unit on an unstable cart stand or shelf. Serious injury to an individual, and damage to the appliance, may result should it fall.</p>



Caution

When the product is not used for an extended period of time, it is advisable to disconnect the AC power cord from the AC outlet.

Caution

The panel used in this product is made of glass. It can break if the product is dropped or if force is applied to the panel. Individuals should execute caution when dealing with broken glass should the panel break.

Exemptions

- Cybercast is not liable for any damage caused by fires, natural disaster (such as thunderstorms, earthquake, etc.), acts by the third parties, accidents, owner's misuse or use in other improper conditions.
- Cybercast is not liable for incidental damages (such as profit loss or interruption in business, modification or erasure of record data, etc.) caused by use or inability to use of product.
- Cybercast is not liable for any damage caused by neglect of the instructions described in the owner's manual.
- Cybercast is not liable for any damage caused by misuse or malfunction through simultaneous use of this product and the connected equipment.

Introduction


Thank you for purchasing the unit. Your unit will bring you years of high-quality viewing enjoyment. The appliance is easy to operate and provides exceptionally high quality image. The manual will explain the operation of the unit, including its functions, features and other important features. Before installing or operating your unit, please take the time to thoroughly read this manual, particularly the sections on safety.

Thanks for purchasing the unit. The latest news, software, utility, driver, product, manual and Q&A will be found at Cybercast website.


[Http://www.cybercast.com.au](http://www.cybercast.com.au)

Stand Installation

Before performing work, please lay the appliance on the stand to prevent it from being damaged. Fix the stand and the unit together with screws. To remove the stand, reverse instruction as above
 Black Screws: M8X30mm(X8)




Antenna Assembly Diagram



Before installation


Insert the Antenna
Rotate Clockwise, Tightening




Installation finished

Connecting the Power Cord

Connect the power cord directly to the wall outlet.



Insert the power cord



Logging in

Login with your provided Cybercast account information. That includes a username and password.

Please login using your username and password

Username:

Password:

Device Manager

This is where you will manage your new or unassigned devices and create locations for them.

Start by entering a suitable name for the location of your digital display. Then press **Save**.

Your new location will now display under the **Device Manager** section.

Click on the tab called - All Devices. Your digital displays should appear here. Simply click assign. Then simply select your location and apply.


You have now assigned your digital display to your location.

Please proceed to Media Manager on the left-hand side menu.

Media Manager


This is where you will manage your media files, such as an image or video file.

Start by entering a name for the Folder you wish to import your media to. Click **Add Folder**.



Select the Folder in the Folder view.

To add files to the folder click **Add File**.




Select the files you want to import using the **Browse** button.


To add files to the folder click **Add**.

Campaign Manager


This is where you will choose a template and attach media files to the template for your ads.



To start a new campaign, simply click on **Add Campaign**.



Type in a name for your campaign in the field provided.




Then choose the template that best suits your advertisement.

Some templates can have sections allocated for videos or even scrolling text.


You can simply use the filter template options to find a suitable template.

* Be aware that you have the right artwork dimensions when adding media files to your Template.

Campaign Manager




Click on the template. You will now have the ability to upload files to the template. Click on the section you want to upload the media file.




A popup will appear, where you'll be able to select your media files you have uploaded in Media Manager.


Campaign Manager




Complete the rest of the sections and when you're done, press **Save**.
Or press **Cancel** if you want to choose another Template.



Once saved, your campaign will be listed under **Campaign Manager**.



If you need to remove your campaign, click the bin icon to remove.



Schedule Campaign

After completing your first campaign, proceed to Schedule Manager on the left-hand side menu.

Package Contents



1pc Main Unit




1pc Stand




Bolt: 8pcs M8x30mm




Gasket: 8PCS OD17XID8.2XT0.7




Gasket: 8PCS Spring Shim




Antenna



1pc Warranty Card



1pc Quick Installation



Power Cord

Power Source	~100-240V AC, 50/60Hz	
Electric Current	1.6A MAX	
Panel Spec	Effective Display Area	1209.6mm x 680.4mm
	Panel Native Resolution	1920 x 1080 pixels
	Brightness	300cd/m ²
	Contrast Ratio	4000 : 1
	Color Depth	8bit, 16.7 Million colors
Input/Output	USB IN	USB X 2
	LAN	RJ45 x 1
	SD CARD	SD CARD SOCKET X 1
	HDMI Out	HDMI X 1
Wireless LAN Specification	Standard	IEEE802.11 802.11b/g/n
	Frequency Band	2.4~2.4835 GHz ISM Band
Audio Power	5W + 5W	
Unit Dimension	790(L) x 463(W) x 1935.8(H)mm	